



HD-3F12B Master Controller Manual

Version:V4.1

Shenzhen Hongda United Technology Co.,Ltd.

Apr,2022

CONTENT

Overview	3
I. Features	3
II. Design Concept	4
III. Expansibility	4
Specifications and Parameters.....	4
I. Controller Appearance	4
II. Controller Three View Size Chart.....	5
III. Controller panel buttons	6
IV. Controller basic Parameter Table:.....	6
Display Description.....	7
I. LCD Main interface After HD-3F12B is Turned on.....	7
II. HD-3F12B Remote Control Settings	8
III. How to Set WAIT Mode.....	16
IV. The Remote Operation of Playing	17
Install and Use	17
I. Offline Mode	17
II. Online/Offline integrated Mode.....	18
Attentions	19
I. Cat.5e Twisted Pair Application Notes	19
II. HD-3F12B Controller SD Card Application Notes	19
III. Controller Connect to Ground Application Notes	19

Overview

I. Features

1. HD-3F12B Supports a Maximum Load of 450,000 Channels;
2. HD-3F12B Support Unlimited Cascade Transmission, Unlimited Number;
3. The System Supports Automatic, Timing, Holiday Preset Effect Play back;
4. Support Buttons and External Remote Control, Program Selection, Brightness Adjustment, White Balance Adjustment, Playback Speed Adjustment and etc;
5. Support Switch Parallel Scheme: improve Stability;
6. Support Offline Fix, Clear Device ID Number;
7. Support Multi-Loop Ring Backup, One Controller is Broken or The Network Cable is Broken and The Display is Not Affected;
8. Support Real-Time Hot Backup of Multiple Master Controllers;
9. Support DMX512AP-N / NB UCS512 TM512 WS2821 and Other Drive Chip Offline Writing Addresses;
10. Independent Brightness Control of 3 Primary Colors, Easy to Adjust White Balance;
11. Support R, RB, RGB, RGBW, RGBWY, and Multi-Color Mixing Control;
12. Using Ethernet Interface and UDP Protocol, The Distance is 100 Meters;
13. LCD Display Module Displays Controller Parameters and Status in Time;
14. SD Card Storage, Can Support 64G, Can Preset 99 Program Files;
15. Support Multiple Devices LAN Remote Online Download and Update Programs;
16. Built-in Animation Test Program;
17. Supports Mixed use of Different Types of Lamps and Lamps of Different Protocols;

18. Equipment Network Port, Surge Protection: 1.5KV;
19. Support Severe Working Environment -40°C-80°C, Normal Operation Without Failure.

II. Design Concept

1. 1000Mbps/ 100Mbps Optional, Adapt to Different Project Schemes;
2. Two-way Redundancy of The System Signal, Doubled Stability;
3. Integrated Control,Online Priority, Automatic Switching Offline Effect Without Signal;
4. Self-developed Playback and Wiring Software,More Adaptable;
5. Support Mainstream 32Bit and 64Bit Systems: Win 7, Win 8 Win 10and so on;

III. Expansibility

1. Can Play Video and Picture File Content in Various Formats;
2. All Current Windows Systems and Multiple Languages Can be Installed;
3. Leave The Interface for Compatibility With International Common Protocols

Specifications and Parameters

I. Controller Appearance

HD-3F12B Front view:




HD-3F12B Rear view:




- ① Power Switch ② Key Control Panel ③ LCD Display ④ Power Lights ⑤ Signal Lights
 ⑥ SD Card Slot ⑦⑧ Self-adapting Network Interface ⑨ Power Interface

II. Controller Three View Size Chart

HD-3F12B Front View:



HD-3F12B Top View:



HD-3F12B Rear View



Remark: Above Three Views The Size Unit is mm.

III. Controller panel buttons













IV. Controller basic Parameter Table:

Product Name	Standard Master
Product Model	HD-3F12B
Rated Voltage	AC 100V ~ 240V±15%Vac50/60Hz
Rated Power	About 15W
Protocol	RJ45X2PCS, Standard UDP/TCP Protocol
Network Rate	100MB/1000MB Adaptive
Relative Humidity	About 95% (Non-Condensing)
Temperature	-40°C ~ 80°C;
Length	283mm
Width	134mm
Height	45mm
Hole Spacing	268mm; 68 mm
Protection Class	IP20

Installation Method	Fixed Hole Installation Method (See Above Drawing)
Weight	1.48kg
Shell Material	Iron (dusting process)
Accessories	Power Cord x1/Warranty Card x1/Foam Paper Box x1/ Screwdriver x1/Card Reader x1/SD Card x1

Key Definition






	Play Switch		Time/Number 0
	Addressing Key		Left Button
	MENU		Plus
	Exit Settings		Minus
	OK		Number key

Display Description


I. LCD Main interface After HD-3F12B is Turned on

MR-3F12B NO CARD	← Model
	← Status: <u>SD Card Not Detected</u>
MR-3F12B NO File	← Model
	← Status: <u>Invalid File or SD Card Format Error</u>
SD 01/08 LoopPlay	← The Number of Programs and The Current Play Number
	← Status: <u>Loop Play Status</u>
SD 01/08 TFixPlay	← The Number of Programs and The Current Play Number
	← Status: <u>Temporary Play Status</u>
SD 01/08 TimePlay	← The Number of Programs and The Current Play Number
	← Status: <u>Timing Play Status</u>



II. HD-3F12B Remote Control Settings

HD-3F12B Press  to Enter the MENU, and Press   to Select in This interface,


as Shown in The Figure Below:





MENU:1

Press  to Enter Clip Settings, Then Press  to Switch Menus,



as Shown in The Figure Below:










MENU:2

Press  to Enter enter Set DMX Address, Then Press  to Switch Menus,

as Shown in The Figure Below:




Press  in Turn to Switch to Select DMX512AP/UCS512/MR-DMX05/TM512/SM16512/UCS512C and Other Driver Chip Models, Press the Plus/Minus Key to Set the Number of Channels or Initial Channels of its Unit Lamps, Press  to Edit Address Write.

Note: In the Normal State of the Video Player, Long Press it to Directly Enter The Access interface of DMX512 Drive Chip, and Switch to Select DMX512AP / UCS512 / MR-DMX05 / T M Drive Chip Model / T 512 / SM16512 / UCS512C, Set the Number of Channels or Starting Channels of its Unit Lamp, and Press the Address Writing.

MENU:3

Press  to Enter the Animation Test, Then Press  to Switch Menus,

as Shown in The Figure Below:



Point By Point

Red

Green

Blue

05-Test3
W 000

White

06-Test3
RGBW

Jump

07-Test3
COLOR

Colorful Gradient

08-Test3
R 001

Red Grayscale

09-Test3
G 001

Green Grayscale

10-Test3
B 001

Blue Grayscale

11-Test3
W 001

White Grayscale

12-Test3
A 001

RGBW Grayscale

13-Test3
HLIN0001

Port by Port Test

Note: HD-3F12B Press  to Enter The Self-Check interface;

In The TEST interface, Click  to Switch the Number of Colors:

In LINE Point-by-Point Test Mode, Click   to Switch to Manual Mode;

In HLIN Port by Port Test Mode, Click   to Switch to Manual Mode;

In The TEST Self-Check interface, Press  in Sequence to Switch Between Multiple Self-Check Modes;

In The TEST Self-Test interface, Press  in Sequence to Exit The Self-Test Mode.

MENU:7


Press  to Enter the Factory Reset, Press   in Turn to Switch The Settings Menu,

as Shown Below:

—MENU:7— *Default	← MENU: 7
	← Reset


I. System Button Settings

MENU:1 interface, Press **OK** to Enter The Segment Setting interface, Press **MU** in Turn to Switch The Setting Menu,As Shown Below:




In This interface, You Can Press **↑** **↓** to Adjust The Program Number and Cycle Mode, and Press **OK** to Save and Exit The Settings.

Press **MU** Again to Enter The Playback Speed Selection interface, as Shown Below:




In This interface, You Can Press **↑** **↓** to Set The Playback Speed, and Press **OK** to Save and Exit The Setting.


Press **MU** again to Enter The Lighting Brightness Setting interface, as Shown in The Following Figure.






In This interface, You Can Press **↑** **↓** to Set The Brightness, and Press **OK** to Save and Exit The Settings.


Press **MU** Again to Enter The Setting interface for Brightness Adjustment of A, B, C, and D Channels, as Shown in The Following Figure:








In This interface, You Can Press   to Set The Brightness, and Press  to Save and Exit The Settings.



Press  Again to Modify The Sub-Control Fixed ID Number interface, as Shown Below:





In This interface, You Can Press   to Fix All The Sub-Control ID Numbers Connected to The Main Control.




6. Press  Again to Clear The Sub-Control Fixed ID Number interface, as Shown Below:




In This interface, You Can Press   to Clear all Sub-Control ID Numbers Connected to The Master.

7. Press  Again to Enter The Client Setting interface, as Shown Below:







In This interface, You Can Press   to Set The Client, and Press  to Save and Exit The Settings.

8. Press  Again to Enter The Master ID Setting interface, as Shown Below:







← Switch


In This interface, You Can Press   to Set The Master ID, and Press  to Save and Exit The Settings.

9. Press  Again to Enter The Wireless Synchronization Setting interface, as Shown Below:




In This interface, You Can Press   to Fine-Tune The GPS Sync Time Settings, and Press  to Save and Exit The Settings.




10. Press  Again to Enter The External Brightness Switch Setting interface, as Shown Below:





In This interface, You Can Press   to Set The External Brightness Switch, and Press  to Save and Exit The Setting.




11. Press  again to Enter The Specified Program Switch Setting interface, as Shown Below:




In This interface, You Can Press   to Set The Specified Program Switch, and Press to  Save and Exit The Settings.




12. Press  gain to Enter The Local Brightness, Brightness Value and Time Setting interface, as Shown Below:



In This interface, You Can Press   to Set The Timer Switch, Brightness, and Time, and Press  to Save and Exit The Settings.

13. Press  Again to Enter The UDP Protocol ID Setting interface, as Shown Below:




In This interface, You Can Press   to Adjust The ID Value Settings, and Press  to Save and Exit The Settings.


III. How to Set WAIT Mode

The HD-3F12B Offline Player Will Enter The Loop Playback of Multiple Clips or Play a Single Clip After Being Powered on. But it is Required That The MR-3F12 Offline Player Does Not Play any Clips After Power-On, and Selects The Playing Clips Through The Remote Control. Such a Playback Mode is The WAIT Mode.

In The Main interface of HD-3F12B, Press  to Enter The Menu Selection and Setting interface, in This interface, You Can Press   to Select Different Function Options; **MENU:1** interface, Press  to Enter The Clip Setting, and Press   to Switch The

Setting Menu, as Shown in The Figure Below:



In This interface, Press  to Save and Exit The Settings.





IV. The Remote Operation of Playing

1. Close Master Controller Playing

When HD-3F12B Playing Press  Can Switch Master Controller Play . LCD Display


Screen Shows : "PLAY OFF" , The Lamps Become Black.

2. Adjust The Program Fragment

When Some of The Fragment Paving , Can Pre:   or   Remote Controller

Number Key to Adjust Playing Fragment .


3. Check The Master Controller Current Time

In The HD-3F12B Master Controller Playing interface Press  The Current Master Time Can be Displayed on The LCD Display.

Install and Use


I. Offline Mode

HD-3F12B is Connected to The Sub-Controller, as Shown in The Following Figure:



II. Online/Offline integrated Mode

Connected With PC and Controller (Online Signal Priority, If No Online Signal it Can Automatic Switch to Offline Signal) as Follows :



Attentions

I. Cat.5e Twisted Pair Application Notes

568B: orange-white/orange/green-white/ blue/blue-white/green/brown-white/brown

568A: green-white/green/orange-white/blue/blue-white/orange/brown-white/brown



Controller and Offline Master Controller and Switch These Three Devices Between Each Other Using a Crossover Cable is Better, One Head is 568B, The Other Head is 568A. Above Any Equipment and Computer Room With a Straight Line, That is Both 568B or 568A, Do Not Define The Order of The Straight Line.

II. HD-3F12B Controller SD Card Application Notes

HD-3F12B SD Memory Card is Used on The Controller, Need to Use The FAT32 File System to Format and Then to Store The Corresponding Offline Files.

III. Controller Connect to Ground Application Notes

HD-3F12B Controller Using Metal Case, Rated Supply Voltage is AC100V-240V, Therefore, It is Necessary to Ensure The Effective Grounding of The Controller Equipment and The Effective Grounding of The Metal Outer BOX.